

Instructions

Install 3 Bike Carrier Hold-Knobs

PARTS LIST

1. (3) HOLD-KNOBS
2. (1) TOP PLATE
3. (1) VERTICAL POST
4. (2) PINS
5. (2) CLIPS
6. (2) BOLTS
7. (2) NUTS
8. (1) MAIN TUBE



BC-X808-4

Install 2 Pins
with Clips

Install a Trailer
Hitch Ball

Install 2 Bolts
and Nuts



TOLL FREE 1-888-651-3431

DISCOUNTRAMPS.COM LLC

760 S. INDIANA AVE.

WEST BEND, WI 53095