



TRUCK N' BUDDY

MODEL: TNB 2000

⚠ WARNING

READ ALL INSTRUCTIONS BEFORE USING THE TRUCK N' BUDDY
NOTE: Failure to read instructions before use could result in injury or death.

Instructions for Installation and Use:



Fig. 1

Contents: See Fig. 1

1. 1 ea. Truck N' Buddy assembled frame
2. 6 ea. 1/4" x 1 1/2" machine screws
3. 1 ea. Grab rail
4. 2 ea. 1/4" x 1 3/4" bolts
5. 2 ea. Flat washers
6. 2 ea. 1/4" Locknuts

STEP 1

Select desired location on tailgate of truck making sure the bottom stabilizing angle is flush against top of tailgate. Mark selected holes with pencil for drilling. NOTE: A minimum of (8) machine screws should be used for secure mounting. **See Fig. 2**



Fig. 2

STEP 2

Remove TRUCK N' BUDDY and drill pilot holes where marked using a 1/8" drill bit. **See Fig. 3**



Fig. 3

STEP 3



Fig. 4

Replace TRUCK N' BUDDY over drilled holes and fasten to tailgate using the (8) machine screws provided. **See Fig. 4**

STEP 4

Attach grip rail to desired side of TRUCK N' BUDDY using 2 ea. 1/4" x 1 3/4" bolts, flat washers, and locknuts. Tighten securely. **See Fig. 5**



Fig. 5

STEP 5



Fig. 6



Fig. 7

Remove bungee securing strap, to unfold TRUCK N' BUDDY to its usable position. **See Fig 6 and 7.**

STEP 6



Fig. 8

Reverse this procedure to return the TRUCK N' BUDDY to its compact traveling position. **See Fig 8.**

⚠ WARNING

NEVER EXCEED THE 300 LB. WEIGHT CAPACITY OF THE TRUCK N' BUDDY.

⚠ WARNING

TRUCK N' BUDDY SHOULD ALWAYS BE IN THE FOLDED AND SECURED POSITION WHILE VEHICLE IS IN MOTION. NEVER ALLOW ANYONE TO RIDE ON THE TRUCK N' BUDDY WHILE VEHICLE IS IN MOTION.

For more information about this or other products, contact us at:

Great Day, Inc.

604 Kimbrough Dr. * Tallulah, LA 71282 * (866) 649-1918 * www.greatdayinc.com