

MC-BEDRACK INSTALLATION INSTRUCTIONS

TOOLS REQUIRED:

Drill
1/2" Drill Bit
18/19mm wrenchs
Tape Measure
Marker
12/13mm wrenchs (for MC-BEDRACK-EXT)
Block of scrap wood (optional)

WARNING:

Installing the MC-BEDRACK requires drilling holes into the bed of your pickup truck. Please make sure all measurements are exact before drilling.

Do not exceed the recommended capacity of 2 motorcycles (3 with extension).

MC-BEDRACK includes a 1 year warranty against defects to the product. This warranty excludes rust and/or corrosion or improper installation of the product.

INSTALLATION:

NOTE:

If installing the MC-BEDRACK-EXT, attach to MC-BEDRACK with the (2) 7mm wrenches before bolting to your truck bed.

STEP 1.

Measure the width of the front of your truck bed box and divide this number by 2. Measure from one side of the truck box in with that number to determine the center of your truck bed. Mark the center of the truck bed box for reference.

STEP 2.

Place the bed rack on the truck bed box with the center mounting hole matching the center mark from Step 1. Position the rack as high as possible on the truck bed box. If your truck bed box has a lip at the top, the rack should fit squarely underneath the lip. Once the rack is centered and lined up, make a mark through the center mounting hole on the truck bed box. This is where your center mounting hole will be drilled.

STEP 3.

RECOMMENDED:

Slide a block of scrap wood (optional) in between the truck bed box and the truck cab before drilling to prevent punching through the truck cab.

Using the drill and 1/2" drill bit, drill a hole through the truck bed box at the mark from Step 2.

STEP 4.

Once the center hole is drilled, install the rack with the center bolt. Telescope out the ends to the sides of the truck bed box. Do not butt the ends up against the side of the truck bed box. Leave enough room for tie down straps to be used on each end without interference from the sides of the truck bed box.

Make sure the rack is level and mark through the holes on each side. Repeat Step 3 for drilling the side holes.

STEP 5.

Using the (2) 12mm wrenches, tighten all the bolts tight. *Congratulations! Your new MC-BEDRACK is installed!*