

Black Widow

BW-T6 PADDOCK STAND INSTRUCTIONS

PARTS LIST



2 WASHERS

2 NUTS

2 BOLTS

2 SPOOL ATTACHMENTS

ASSEMBLY

FOR SAFETY REASONS, PLEASE USE PROPER CARE WHILE OPERATING THIS REAR PADDOCK STAND WITH YOUR MOTORCYCLE

STEP 1.
INSERT EACH **TRUSS SUPPORT** INTO THE **TOP FRAME**. USING **BOLTS, WASHERS** AND **NUTS** TO SECURE THE FRAME TOGETHER.



TO ENSURE THE ASSEMBLY IS PROPERLY ALIGNED, MATCH THE RED CIRCLED "R" (FOR REAR) TOGETHER.

STEP 2.

INSERT AND ADJUST THE **SPOOL ATTACHMENTS** ON EITHER SIDE TO THE DESIRED SPOOL WIDTH FOR LIFTING.



STEP 3. OPERATION

SLIDE THE STAND UNDER THE MOTORCYCLE'S REAR SPOOLS AND PUSH DOWN ON THE STAND HANDLE IN ORDER TO LIFT THE MOTORCYCLE

