

# Installation instructions for FlexRamp slide-out mounting system

1) Position the ramp just inside the rear doors of the SUV or van. Make sure the slide-out feature of the mount system is positioned as far as it can from the doors. The 1" x 1" square tubing on both sides of the mounting system should be as close to the doors and threshold as possible but should not interfere with closing of the doors. Mark the location of the four mounting holes at each end of the 1" x 1" tubing for the specific point to drill the mounting holes in the floor of the van or SUV.

2) The slide-out mounting system allows the ramp/steps to slide-out 5.5" over the threshold and bumper. You must mount the system so there is space between the floor and 1" x 1" slide rail so the ramp/steps can freely slide in and out of the vehicle over the threshold. There are spacers included with all systems to provide the space between the floor and 1" x 1" slide bar. NOTE: If the floor covering is exceptionally thick you may need additional spacers to allow the slide-out to function freely.

When installed properly the ramp/steps will slide-out over the threshold and bumper freely prior to extending the ramp or steps.

If you have any questions please call:  
**800 478-2363**

