



53360 – Front Gear Basket

Item	Description	Quantity
1	Welded Basket	1
2	Cross Brace	4
3	¼" U-Bolts	4
4	¼" Nylon Nut	8
5	Rubber Cap	8



Mounting Instructions:

1. Place the Basket on either the front or rear rack of your ATV in your desired position.
2. Next, take the U-Bolts provided and bring the from under you ATV Rack and up through the meshing. Ideally you will want the U-Bolts to go around the strapping on the base of the Basket. This will provide the most secure mounting application. If the straps cannot be reached, position the U-Bolt as close as possible to the straps provided.
3. Now, place the Metal Cross Brace over the top of the U-Bolt, and secure with Lock Nuts.
4. Next, tighten the Nylon Nuts equally until the rack is secure. Place the Rubber Caps over the extra thread for safety.

NOTE: Be sure to periodically check hardware, as vibration will tend to loosen hardware over time.

NOTE: Extra length is given on the u-bolt to allow numerous ATV applications. If too much extra thread is showing you can cut the u-bolt to accommodate your use.

Drop Basket Use:

- Note that the Basket is designed to transport only as much as your ATV recommends. Do not carry more than the ATV manufacturer recommends, as too much weight can result in loss of steering and could lead to serious injury or death.

Kolpin Outdoors, Inc.
205 N. Depot Street, Fox Lake, WI 53933
Phone #: (877) 9KOLPIN or (920) 928-6514
www.kolpinpowersports.com customerservice@kolpin.com