

Hitch Carrier Light Kit

Instructions

1. With the carrier attached to the vehicle, place the light on the carrier.
2. Route the cable to the vehicle's wiring harness, and connect it to the flat 4 trailer plug.
3. Secure any extra cable to ensure that it does not drag on the ground.

Repositioning/Removing Magnets

If mounting product permanently to a carrier or basket, skip step 5

1. Use a philips-head screwdriver to remove the four screws holding each of the white end caps on the sides of the light bar.
2. Once the screws are removed, pull on the white end caps to remove them. A tab on the side of each cap allows for use of a small flat-head screwdriver to aid in removing the cap if necessary.
3. Use a philips-head screwdriver and a 7/16" (or 11mm) wrench to remove the bolt and nut holding the magnet in place. Repeat this process on the opposite side.
4. Drill 1/4" holes in the new locations where the magnets are to be placed. Note: the cord from the light should always be facing the ground.

5. Line up the hole in the magnet with the new hole in the light. Insert the bolt through both, and attach the nut. Tighten, and reattach the end cap. Repeat this process for the other side.

6. (For permanent mounting) Using the holes in the lightbar as a template, drill holes in side of the carrier or basket that the light is to be mounted to. Line up the holes in the light bar with the holes in the carrier or basket. Insert the bolt through both, and attach the nut. Tighten, and reattach the end cap. Repeat this process for the other side.

