



CAR/JEEP/SUV/VAN COVER

User's Manual

■ BEFORE USING THIS COVER

1. Make sure the surface of the vehicle and the cover is both clean and dry before fitting.
2. In certain weather conditions, it may be necessary to remove the cover every couple of days to allow possible condensation of moisture to dry out. Never place the cover on a wet vehicle.
3. When using the cover, take care not to pull from side to side too vigorously. This will avoid damaging the seams.
4. This cover is designed to protect your vehicle from hazardous elements. The life expectancy depends on the weather conditions and also the care taken when using and storing the cover.

■ INSTALLATION

1. The front of the cover is marked with an "Allow mark" to help you get it positioned correctly on the car.
2. If your vehicle has an outside radio antenna that doesn't unscrew or retract flush with the vehicle body, you will have to provide an opening in the cover. Place the cover over the antenna before moving to the next step.
3. If your cover has side-mirror pockets, position the cover over the mirrors.
4. Stretch the ends of the cover over the front and rear bumpers.

■ CLEANING AND CARE

Car Cover is machine washable, note below and choose the best way to treat your car cover.

1. Normal dirt and grime: Hand clean small areas with a small brush or soft terry cloth.
2. Machine wash: The cover can be machine washed at a Laundromat in a large commercial unit without an agitator. Use 2 cups of cleaner. Rinse thoroughly making sure all cleaner is removed. Use an extra rinse cycle if necessary.
3. Air dry only. **Do not machine dry.**

■ IMPORTANT SAFETY WARNING

1. RE-PAINTED VEHICLE:

- Never cover a repainted car

2. TAIL PIPES:

A hot exhaust tail pipe may melt the cover.

- Wait approximately 10-15 minutes for cool down before placing the cover.
- Use care when installing this cover on a vehicle that has just been driven.

3. HIGH WINDS:

In severely windy conditions, "ballooning" of the cover may occur.

- It is strongly recommended that your car be sheltered whenever high winds are expected.
- Using an optional (not included) bungee cord or cable through the grommet areas may also help prevent "ballooning".

4. FREEZING WEATHER:

- Do not remove the cover from an ice covered vehicle. Make sure the ice has melted before removing.
- You may facilitate the thawing, by pouring warm water over the cover and gently lifting the cover as the ice melts.



CAUTION

1. If the car has just been driven, be careful not to allow the cover to come in contact with hot exhaust pipes.
2. Some vehicles may have sharp bumpers, hood ornaments or moldings. You can minimize abrasion and the possibility of tearing the cover by reinforcing the inside of the cover and taking extra care when installing and removing the cover.