

Deluxe Jet Ski Cover

Instructions for Part # 67131, 67132, 67133



General Guidelines ⚠

- It is the user's responsibility to read and follow all instructions.
- Keep these instructions with the product at all times and review before each use.
- It is the responsibility of this product's owner to furnish the instructions to any person that borrows or purchases the product.
- Inspect the product before use to ensure it is assembled properly and all parts are in safe working order and free of defects.
- Never modify this product in any way.
- All circumstances cannot be addressed in these instructions. Please use common sense and practice general safety measures when using this product.
- Parts and/or instructions are subject to change without notice.
- Always tie the cover down securely.

Care & Maintenance

- Make sure the surface of the personal watercraft is clean and dry before fitting.
- When using the cover, take care not to pull from side to side too vigorously. This will prevent damaging the seams.
- Avoid letting water or snow stand on the cover - use support poles, straps, or bows. Damage to the cover caused by standing water is not covered under warranty.
- Take the precaution of padding any sharp points before installing the cover. Damage to the cover caused by failure to cover sharp areas is not covered under warranty.
- Allow the cover to dry thoroughly before folding for storage.
- The cover may be cleaned with a soft bristle brush or cloth and water.

Cover Color

- All covers are treated for UV protection. Covers will fade at different rates due to exposure time in the sun.
- The color fading does not affect the materials or durability of the cover.
- Fading material is not covered under the warranty.

Installation

1. Begin by covering any sharp edges with towels or cardboard to prevent tearing the cover.
2. Remove the cover from the storage bag and unroll it. Locate the front of the cover, identifiable by a tag sewn into the underside of the cover. Drape the front of the cover over the front of the PWC.
3. If using support poles (not included), position the poles before proceeding to step 4.
4. Pull the cover over the entire PWC, pulling the sides below the rub rail.
5. Adjust cover fit by pulling the cover tight to eliminate sagging areas. Such areas may collect standing water or snow, shortening the life of the cover.
6. Tie down straps are included with the cover. Each strap attaches to buckles on the bottom edge of the cover. Attach one end of the strap to the buckle, then run the strap under the PWC and attach it to the corresponding buckle on the other side. Make sure each strap is even and snug.

Product Warranty and Liability

GENERAL PRODUCT WARRANTY: Products purchased from the Authorized Dealer (original place of purchase) or Merchant (“Dealer”) will be free of defects in material and workmanship at the time of receipt, and will meet the specifications stated at the place of purchase transaction or online at the Dealer’s website, under normal use and service when correctly installed, operated and maintained. This product warranty is effective for the period of time stated below, unless otherwise stated in the product instructions or depicted in the product advertisement. **All Authorized Dealer warranties are NON-TRANSFERABLE** and cover only the original end purchaser. This limited warranty does not cover products purchased through non-authorized dealers. Non-authorized dealer receipts are not accepted for warranty verification.

*****Warranty claims must be made directly to the original place of purchase.*****

WARRANTY PERIOD: This warranty remains in force for one year from the date of the product’s accepted delivery. The Authorized Dealer offers a one year manufacturer’s warranty for most products unless otherwise specified on the product advertisement.

WARRANTY SERVICE: The Authorized Dealer will replace any defective or malfunctioning part at no charge, including payment of the shipping costs of parts or replacement product to and from the manufacturer. The purchaser is responsible for labor charges. If the product does not meet specifications as depicted in the advertisement, the Authorized Dealer will refund the full purchase price of the product.

Questions regarding the warranty on a specific product and warranty claims should be directed to the Authorized Dealer with whom the purchase transaction was made.

WARRANTY LIMITATIONS: The above warranty does not apply to products that are repaired, modified or altered by any party other than the Authorized Dealer; are subjected to unusual physical stress or conditions (such as overloaded ramps or corrosion), natural disaster, governmental actions, wars, strikes, labor disputes, riots, theft, vandalism, terrorism or any reason beyond reasonable control; are damaged due to improper installation, misuse, abuse, accident or negligence in use, storage, transportation or handling, or tampering; or to products that are considered consumable items or items requiring repair or replacement due to normal wear and tear.

Product should be inspected prior to signing for delivery. Product damage incurred during shipping, unless noted on the Bill of Lading at the time of delivery, renders this warranty void.

LIMITED LIABILITY: In no event shall THE AUTHORIZED DEALER be liable to the purchaser or any third party for any indirect, incidental, consequential, special, exemplary or punitive damages arising out of the use of the product, including, without limitation, property damage, loss of value of the product or any third party products that are used in or with the product, or loss of use of the product or any third party products that are used in or with the product.

