



# DEER CART OWNERS INSTRUCTION MANUAL

CRAWLER DEER CART MODEL: 3420

**YOU MUST READ, UNDERSTAND, FOLLOW ALL WARNINGS AND INSTRUCTIONS USING THIS PRODUCT!**

## **WARNING**

**CONTACT HAWK AT 810-626-3026 OR CONTACT@HAWKHUNTING.COM WITH QUESTIONS.**

**FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN SERIOUS INJURY OR DEATH!**

**Never ride, sit, or stand in Deer Cart. Not designed for human transportation.**

**Never use on roads. Cart is not designed for road use and is not street legal.**

**Never use or pull cart at speeds greater than 10mph.**

**Maximum Weight Limit – 500lbs. Never exceed maximum weight limit.**

**Never exceed maximum tire air pressure of 25p.s.i.**

**FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN SERIOUS INJURY OR DEATH!**

## **WARNING**

TABLE OF CONTENTS	
Safety Information	1
No Alterations	1
Parts List & Nomenclature	2
Assembly	2
Maintenance & Storage	3
Trouble Shooting	3
Limited Warranty	4
Product Registration	5

### IMPORTANT SAFETY INFORMATION:

- Inspect cart each time before use for any damage, including but not limited to corrosion, wear, damage, deterioration, vandalism, fraying or other damage. DO NOT USE THIS PRODUCT if damage is visible or suspected. If there are any questions, DO NOT use the product and contact HAWK™ at 810-626-3026 or e-mail support at contact@hawkhunting.com.
- Before each use make sure frame, axles, nuts, bolts and threaded knobs are secure.
- If under age of 18 do not use without adult supervision.

### NO ALTERATIONS OR MODIFICATIONS:

#### NO ALTERATIONS OR MODIFICATIONS:

This product is designed to function properly in its original condition. Alterations or modifications can make it unsafe and constitute a misuse of the product. Do not alter, add, modify or substitute parts or accessories not made by HAWK™.


**THIS INSTRUCTION MANUAL MUST ALWAYS ACCOMPANY THIS PRODUCT AND BE TRANSFERRED WITH IT UPON CHANGE OF OWNERSHIP, WHEN LOANED, OR PRESENTED TO ANOTHER PERSON.**

## PARTS LIST AND NOMENCLATURE:

- Tools Required:
  - 2 – 13mm Wrenches (included)
  - Adjustable Wrench (not included) for Wheel Assembly
- Unpack and Check
- Review & Confirm all items are included in Package Contents. If they are not, stop and contact customer service at 810-626-3026 or e-mail support at [contact@hawk hunting.com](mailto:contact@hawk hunting.com) before continuing or using this product.

### CRAWLER DEER CART PARTS LIST:

Qty	Description
1	Main Frame Assembly (1)
1	Rear Frame (2)
2	Axles (3)
2	Wheel Assembly (4)
1	Handle (5)
1	Bolt Pack
	2 – M8x50mm bolt, 2 steel washers & 1 nut
	2 – M6x30mm bolt, 2 steel washers & 1 nut
	2 – Thick nylon washers & steel washer
	2 – M16 large axle nut




## ASSEMBLY:




**QUESTIONS CALL 810-626-3026. Do not overtighten bolts. Tighten bolts so connections are secure using supplied wrenches.**

### ASSEMBLY



- 1 Rear Frame Assembly**  
Attach Rear Frame(2) to Main Frame(1) with (2pcs) M8x50mm bolts, 2 steel washers and locknut. Place steel washers on outside and tighten bolts using supplied wrenches.



- 2 Wheel Frame Assembly**  
Insert Pivot Axles(3) into Main Frame and attach with (2pcs) M6x30mm bolts, 2 steel washers and locknut. Place steel washers on outside and tighten bolts using supplied wrenches.



Insert thick nylon washer, wheel assembly(4), thick nylon washer and steel washer onto pivot axle and attach with M16 axle nut. Use adjustable wrench to tighten axle nut onto cart.



## ASSEMBLY CONTINUED:

### ASSEMBLY

3


#### Handle Assembly

Remove triangle knobs and attach Handle(5) to Main Frame with triangle knobs.

*Note – To fold handle loosen triangle knobs and pivot onto frame. Retighten knobs to hold handle in place.*

***Double check to assure all bolts and nuts are tight.***

Cart is ready for use.



## MAINTENANCE AND STORAGE:

### WARNING

**Never exceed maximum tire inflation of 25 p.s.i. Only use hand pump to inflate tire.**

**Use only Hawk authorized replacement parts. The use of unauthorized replacement parts may result in serious injury or death.**

**Always inspect cart for damage including but not limited to corrosion, cracks, deformity, bends, rot, wear, cuts or fraying and other damage. Do not use if damage, wear, deterioration, etc. is detected or suspected.**

**Failure to follow these instructions can lead to serious injury or death.**

Should any damage occur to any part of your cart or to purchase HAWK™ replacement parts, contact nearest HAWK™ dealer or contact customer service at 810-626-3026 or [contact@hawkhunting.com](mailto:contact@hawkhunting.com).

Care and maintenance is required to assure trouble free performance of your cart.



**Store this product indoors and away from exposure to elements when not in use.**

Store indoors in a clean, dry environment free from direct sunlight, harmful chemicals, excessive heat and dust. Exposure to sunlight, excessive heat and the elements can weaken fabric material over time.

## TROUBLE SHOOTING:

PROBLEM	SOLUTION
Cart is damaged.	Do not use. Replace cart.
Missing parts.	Do not use. Contact HAWK™ customer service at 810-626-3026 or at <a href="mailto:contact@hawkhunting.com">contact@hawkhunting.com</a>
Tires are soft or flattened down when loaded.	Do not use. Inflate tires with hand pump. Do not exceed maximum tire inflation of 25psi of air pressure.
Wheels or wheel assemblies are loose.	Tighten wheel nut and or wheel pivot nut.
Wheels do not spin freely.	Slightly loosen wheel nut until wheels spin freely.

## LIMITED WARRANTY\*.

**LIMITED ONE YEAR WARRANTY.** WE WARRANT THIS PRODUCT AGAINST ANY MANUFACTURER DEFECTS IN MATERIALS AND WORKMANSHIP FOR PERIOD OF ONE YEAR FROM DATE OF PURCHASE FROM AUTHORIZED RETAILER TO THE **ORIGINAL, REGISTERED OWNER.** WE WILL REPAIR OR REPLACE ANY PART FOUND DEFECTIVE IF THE UNIT CLAIMED TO BE DEFECTIVE IS RETURNED TO US POSTAGE PREPAID, WITHIN WARRANTY PERIOD. CONTACT CUSTOMER SERVICE AT 810-626-3026 OR E-MAIL AT CONTACT@HAWKHUNTING.COM FOR WARRANTY CLAIMS.

Register within 30 days of your purchase online at hawkhunting.com or mail in completed warranty card.

This warranty is void if any product has been subjected to misuse, abuse, neglect (including but not limited to improper maintenance), storage, improper use, misapplication, accident, normal wear, modification, adjustment, repair or if warranty registration card is not complete and returned.

NO OTHER WARRANTIES WHETHER EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL APPLY TO THE PRODUCT.

### LIMITATION OF LIABILITY

It is expressly understood that our liability for this product, whether due to breach of warranty, negligence, strict liability, or otherwise, is limited to repair of the product as stated above. We will not be liable for any other injury, loss, damage, or expense, whether direct or consequential, including but not limited to loss of use, income, profit, or damage to material from use of this product howsoever caused.

### SERVICING YOUR PRODUCT:

If you need repairs or have warranty issues, contact Customer Service at 810-626-3026 or e-mail at contact@hawkhunting.com for assistance.

### PLEASE NOTE:

We reserve the right to make substitutions on warranty coverage for any reason, including but not limited to available parts.

\*Limited Warranty to the Original Owner.

HAWK™  
Phone: 810-626-3026  
Email: contact@hawkhunting.com  
Website: hawkhunting.com



Distributed By: INNOPOWER INC.  
393 List St., Suite B,  
Frankenmuth, MI 48734

## REGISTERING YOUR PRODUCT

Register your product to validate your Limited Warranty.

Completely fill out registration card below and mail this portion with copy of sales receipt to:  
CUSTOMER SERVICE, 393 List St., Suite B, Frankenmuth, MI 48734.

You can also register online at [hawkhunting.com](http://hawkhunting.com)

LAST NAME:  FIRST NAME:

STREET ADDRESS:

CITY:  STATE/PROVINCE:

ZIP/POSTAL CODE:  COUNTRY:

PHONE:  E-MAIL:

PURCHASE DATE (MONTH / DAY / YEAR):

PURCHASED FROM (RETAILER):

MODEL NAME:

MODEL NUMBER:

DATE CODE (DATE STAMP ON PRODUCT):

By signing and returning this registration card, the user acknowledges he or she has read and understands the safety, warnings, instructions and warranty provided with this product. User accepts said warranties and limitations thereon, as listed.

Signature:  Date:

### IMPORTANT:

Register within 30 days of your purchase online at [hawkhunting.com](http://hawkhunting.com) or mail in completed warranty card received at purchase. Retain copy of sales receipt as this is required should your product ever need warranty service.

HAWK™  
Phone: 810-626-3026  
Email: [contact@hawkhunting.com](mailto:contact@hawkhunting.com)  
Website: [hawkhunting.com](http://hawkhunting.com)



Distributed By: INNOPOWER INC.  
393 List St., Suite B,  
Frankenmuth, MI 48734