




General Guidelines ⚠

- It is the user's responsibility to read and follow all instructions.
- Keep these instructions with the product at all times and review before each use.
- It is the responsibility of this product's owner to furnish the instructions to any person that borrows or purchases the product.
- Inspect the product before use to ensure it is assembled properly and all parts are in safe working order and free of defects.
- Never modify this product in any way.
- All circumstances cannot be addressed in these instructions. Please use common sense and practice general safety measures when using this product.
- Parts and/or instructions are subject to change without notice.

Safety ⚠

- This carrier is designed for carrying skis and snowboards only.
- Never exceed your vehicle rack recommended weight capacity.
- The carrier should always be securely locked closed before driving. Test that the carrier is locked by pressing on the top to ensure it does not release.
- Be aware that skis may interfere with opening of a vehicle rear hatch. Use caution when opening.
- Make sure there is enough clearance for bindings before loading skis.
- Skis should only be placed front to back on the vehicle roof. Never use the carrier to transport items sideways.
- Remove the carrier when not in use or before entering a car wash.
- Always keep track of the keys and store them in a safe place.

Parts



Part	Description	Quantity
A	Carrier Hood (4 or 6 capacity)	2
B	Top Clamp	4
C	Bottom Clamp	4
D	M6x90 Hex Cap Bolt	4
E	M6 Nylon Nut	4

Part	Description	Quantity
F	M6x40 Hex Cap Bolt	8
G	M6 Nut	8
H	4mm Hex Wrench	1
I	5mm Hex Wrench	1
J	Key	2

Assembly

Step 1. Attach two top clamps to each carrier hood using the M6x90 bolts and nylon nuts. Place a nylon nut into the indent on one side of the top clamp. Fit the bolt into the other side of the top clamp, threading it through the clamp and the carrier hood until it meets the nylon nut. Tighten securely with the 5mm hex wrench.




Step 2. Attach the bottom clamps to the top clamps using the M6x40 bolts and nuts. The vehicle crossbar should be between the top clamp and bottom clamp before securing to fix the ski carrier to the vehicle roof. Place a nut into the indents in the underside of the bottom clamp. Fit the bolt into the holes in the top clamp and bottom clamp, meeting the nut. Tighten securely with the 4mm hex wrench.



Use

This roof ski carrier is designed for carrying skis and snowboards only. Two skis/snowboards may be stacked with the bottoms touching. The higher front end of the skis should be facing the back of the vehicle for improved aerodynamics.



To secure the skis in place, firmly close the top of the carrier hood until it latches in place. Lock closed. Some skis may require that you hold down the top of the carrier hood and lock in place in order to stay securely closed. Never drive without both carriers locked closed.



Product Warranty and Liability

GENERAL PRODUCT WARRANTY: Products purchased from the Authorized Dealer (original place of purchase) or Merchant (“Dealer”) will be free of defects in material and workmanship at the time of receipt, and will meet the specifications stated at the place of purchase transaction or online at the Dealer’s website, under normal use and service when correctly installed, operated and maintained. This product warranty is effective for the period of time stated below, unless otherwise stated in the product instructions or depicted in the product advertisement. **All Authorized Dealer warranties are NON-TRANSFERABLE** and cover only the original end purchaser. This limited warranty does not cover products purchased through non-authorized dealers. Non-authorized dealer receipts are not accepted for warranty verification.

*****Warranty claims must be made directly to the original place of purchase.*****

WARRANTY PERIOD: This warranty remains in force for one year from the date of the product’s accepted delivery. The Authorized Dealer offers a one year manufacturer’s warranty for most products unless otherwise specified on the product advertisement.

WARRANTY SERVICE: The Authorized Dealer will replace any defective or malfunctioning part at no charge, including payment of the shipping costs of parts or replacement product to and from the manufacturer. The purchaser is responsible for labor charges. If the product does not meet specifications as depicted in the advertisement, the Authorized Dealer will refund the full purchase price of the product.

Questions regarding the warranty on a specific product and warranty claims should be directed to the Authorized Dealer with whom the purchase transaction was made.

WARRANTY LIMITATIONS: The above warranty does not apply to products that are repaired, modified or altered by any party other than the Authorized Dealer; are subjected to unusual physical stress or conditions (such as overloaded ramps or corrosion), natural disaster, governmental actions, wars, strikes, labor disputes, riots, theft, vandalism, terrorism or any reason beyond reasonable control; are damaged due to improper installation, misuse, abuse, accident or negligence in use, storage, transportation or handling, or tampering; or to products that are considered consumable items or items requiring repair or replacement due to normal wear and tear.

Product should be inspected prior to signing for delivery. Product damage incurred during shipping, unless noted on the Bill of Lading at the time of delivery, renders this warranty void.

LIMITED LIABILITY: In no event shall THE AUTHORIZED DEALER be liable to the purchaser or any third party for any indirect, incidental, consequential, special, exemplary or punitive damages arising out of the use of the product, including, without limitation, property damage, loss of value of the product or any third party products that are used in or with the product, or loss of use of the product or any third party products that are used in or with the product.

