



Snowmobile Dolly

Read, Understand, Follow and Save These Instructions


Read, understand and follow all of these instructions and warnings (Instructions) when using this product. Use this product only as specified in these instructions. Improper use of this product may result in property damage, serious injury and/or death. Never allow use of this product by anyone without providing them with these instructions. You must read, understand and follow all instructions and warnings for any product(s) to which this product is used in conjunction with. Save these instructions with the product for use as a reference for any future use of the product.

⚠ WARNING Failure to follow these warnings and instructions may result in property damage, serious bodily injury and/or death.


- Purchaser/owner must ensure that product is used as intended. Purchaser/owner must not alter or modify product.
- Operator and bystanders should never position any part of body under or behind this product.
- This product is not designed or intended to be used for towing.
- Loading or unloading from this product at high speed could cause loss of control resulting in injury or property damage.
- During loading and unloading keep all persons and personal property clear of dolly.
- Always be sitting on snowmobile during loading and unloading.
- Failure to follow this product's warnings could result in injury or property damage.
- Do not allow children to play on or around this product.
- Never exceed maximum weight capacity of 1,000 lbs.
- Always replace bent, broken or worn parts before using this product.

Assembly Instructions

Warning: Failure to follow these warnings and instructions may result in property damage, serious bodily injury, and/or death.



- 1) Remove nuts from bolts and slide bolts out ("A") from front section of snowmobile dolly.
- 2) Insert tube ("B") into head of snowmobile dolly. Re-insert bolts ("A") into top of front section of snowmobile dolly to hold tube in place. Tighten nuts securely to bolts on bottom side of dolly. Use 1/2" wrench or socket to tighten nuts securely.
- 3) Remove pull pin ("C") from rear section of dolly. Slide rear section onto tube. Replace pull pin at desired length.



Loading/Unloading Instructions

Warning: Failure to follow these warnings and instructions may result in property damage, serious bodily injury, and/or death.

Loading:

1. Roll dolly between skis under the snowmobile so that the rear section (bottom of “T”) is touching the front part of the snowmobile’s track.
2. Make sure the dolly is centered and that the skis are equal distance from the center of the dolly.
3. Adjust the front section so that it is 6” or more from touching the front of the skis.
4. Fully extend braking rope on ground in front of dolly.
5. While sitting on snowmobile start the snowmobile.
6. Making sure you are ready to engage the brake begin to slowly drive onto dolly.
7. Stop snowmobile when the skis are centered on the front section of the dolly.
8. Turn snowmobile engine off and engage snowmobile’s parking break.

Unloading:

- Fully extend braking rope on ground in front of dolly.
- Make sure all objects are clear of the rear of the snowmobile and dolly.
- While sitting on snowmobile start snowmobile and disengage the snowmobile parking brake.
- Make sure all objects and persons are clear of the rear of the snowmobile.
- Making sure you are ready to engage brake, slowly engage throttle to drive snowmobile off of dolly.
- Advance snowmobile past braking rope.

Please note that the plastic will become scarred if a snowmobile with picks is loaded and unloaded. This scarring does not effect the function of the product in any way.

Limited Warranty

Limited Warranty. Sledez (“We” or “Us”) warrants to the original consumer purchaser only (“You”) that the product purchased will be free from material defects in both material and workmanship, normal wear and tear excepted, for a period of **one year**. The foregoing warranty is valid only if the assembly and use of the product is in accordance with product instructions. There are no other warranties, expressed or implied, including the warranty of merchantability or fitness for a particular purpose. If the product does not comply with the applicable limited year warranty, Your sole and exclusive remedy is that We will replace the product without charge to You and within a reasonable time or, at our option, refund the purchase price. This limited warranty is not transferable.

Limitations on the Warranty. This limited warranty does not cover: (a) normal wear and tear; (b) damage through abuse, neglect, misuse, or as a result of any accident or in any other manner; (c) damage from misapplication, overloading, or improper installation; (d) improper maintenance and repair; and (e) product alteration in any manner by anyone other than Us.

Obligations of Purchaser. You must retain Your product purchase receipt to verify date of purchase and that You are the original consumer purchaser. To make a warranty claim, contact Us at PO Box 226A, Malta, IL, 60150, 1-815-895-0400. The product and the purchase receipt must be provided to Us in order to process Your warranty claim. Any returned product that is replaced or refunded by Us becomes our property. You will be responsible for return shipping costs.

Remedy Limits. Repair or replacement is Your sole remedy under this limited warranty or any other warranty related to the product. We shall not be liable for any incidental or consequential damages of any kind.

Assumption of Risk. You acknowledge and agree that any use of the product for any purpose other than the specified use(s) stated in the product instructions is at Your own risk.

Governing Law. This limited warranty gives You specific legal rights, and You also may have other rights which vary from state to state. This limited warranty is governed by the laws of the State of Illinois, without regard to rules pertaining to conflicts of law. The Circuit Court for the Sixteenth Judicial Circuit in DeKalb County, Illinois shall have exclusive jurisdiction for any disputes relating to this warranty.

How to Order

Use only Sledez parts or parts of equal quality for repair. Replacement parts are available through Sledez’s Customer Service Department, 815-895-0400 or info@sledez.com.