



Throne Multipurpose Game Cart  
& Hunting Chair  
Instructions for Part # THRONE  
US PAT. 9,162,692



## General Guidelines

- It is the user's responsibility to read and follow all instructions.
- Keep these instructions with the product at all times and review before each use.
- It is the responsibility of this product's owner to furnish the instructions to any person that borrows or purchases the product.
- Inspect the product before use to ensure it is assembled properly and all parts are in safe working order and free of defects.
- Never modify this product in any way.
- All circumstances cannot be addressed in these instructions. Please use common sense and practice general safety measures when using this product.
- Parts and/or instructions are subject to change without notice.

## Safety

- Do NOT stand on product.
- Always store product in a safe place.
- Improper use, storage, or installation of product could result in damage to the product or injury to the operator.
- Periodically check nuts and bolts for tightness.

---

## Tools Required

- 6mm Allen wrench

# Parts





Part	Description	Quantity
1	Frame	1
2	Wheel	2
3	Folding Seat	1
4	Right-Handed Allen Head Bolt	1



Part	Description	Quantity
5	Left-Handed Allen Head Bolt	1
6	Turn Knob	2
7	Tie Down Strap	2

# Assembly

**Step 1.** Install wheel to frame axle (1a) with recessed side of wheel facing away from frame (1b). Apply the left-handed Allen head bolt (1c). Tighten with 6mm Allen wrench.




**Step 2.** Repeat step 1 with other side (2a) using the right-handed Allen head bolt. Be sure the bolts are in the correct wheels according to thread type. This will help prevent the bolts from loosening when rolling. Make sure frame knob is facing upwards before proceeding onto Game Cart and Throne configurations.



## Game Cart Configuration

**Step 1.** Release handle from frame by pushing inner button (1a - 1b).



**Step 2.** Swing handle around until it locks into position (2a - 2b).



**Step 3.** Install seat to frame (3a).



**Step 4.** Fold seat open (4a).



## Throne Configuration

**Step 1.** Fold seat up and remove from frame (1a).



**Step 2.** Tilt frame onto side with retractable gun holder upright (2a).



**Step 3.** Push button on handle in to fold back into frame (3a). Swing handle into frame to lock in position (3b - 3c).



**Step 4.** Push outer button on frame in (4a). Fold top bar of frame up (4b) until wheel is resting on top of other wheel (4c).



**Step 5.** Install seat to frame (5a). Fold seat open (5b).



**Step 6.** Secure seat to frame with seat turn knob (6) (6a - 6c).



**Step 7.** Turn knob counter clockwise to release retractable gun holder (7a).

Adjust to preferred height.

Turn knob clockwise to lock gun holder into position (7b).




## Throne Use

**Step 1.** Lean forward to prevent throne from moving (1a). Frame rests on wheel providing traction (1b).



**Step 2.** 360° Movement in relaxed position (2a). Frame hovers over wheel (2b).



## Throne Maintenance

If tires make noise in the shooting position, we recommend coating the bottom tire with non-scented hand lotion.



## **PRODUCT WARRANTY & LIABILITY**

**GENERAL PRODUCT WARRANTY:** Products purchased from the Authorized Dealer (original place of purchase) or Merchant ("Dealer") will be free of defects in material and workmanship at the time of receipt, and will meet the specifications stated at the place of purchase transaction or online at the Dealer's website, under normal use and service when correctly installed, operated and maintained. This product warranty is effective for the period of time stated below, unless otherwise stated in the product instructions or depicted in the product advertisement. All Authorized Dealer warranties are NON-TRANSFERABLE and cover only the original end purchaser. This limited warranty does not cover products purchased through non-authorized dealers. Non-authorized dealer receipts are not accepted for warranty verification.

**\*\*\*WARRANTY CLAIMS MUST BE MADE DIRECTLY TO THE ORIGINAL PLACE OF PURCHASE.\*\*\***

**WARRANTY PERIOD:** This warranty remains in force for one year from the date of the product's accepted delivery. The Authorized Dealer offers a one year manufacturer's warranty for most products unless otherwise specified on the product advertisement.

**WARRANTY SERVICE:** The Authorized Dealer will replace any defective or malfunctioning part at no charge, including payment of the shipping costs of parts or replacement product to and from the manufacturer. The purchaser is responsible for labor charges. If the product does not meet specifications as depicted in the advertisement, the Authorized Dealer will refund the full purchase price of the product.

Questions regarding the warranty on a specific product and warranty claims should be directed to the Authorized Dealer with whom the purchase transaction was made.

**WARRANTY LIMITATIONS:** The above warranty does not apply to products that are repaired, modified or altered by any party other than the Authorized Dealer; are subjected to unusual physical stress or conditions (such as overloaded ramps or corrosion), natural disaster, governmental actions, wars, strikes, labor disputes, riots, theft, vandalism, terrorism or any reason beyond reasonable control; are damaged due to improper installation, misuse, abuse, accident or negligence in use, storage, transportation or handling, or tampering; or to products that are considered consumable items or items requiring repair or replacement due to normal wear and tear.

Product should be inspected prior to signing for delivery. Product damage incurred during shipping, unless noted on the Bill of Lading at the time of delivery, renders this warranty void.

**LIMITED LIABILITY:** In no event shall **THE AUTHORIZED DEALER** be liable to the purchaser or any third party for any indirect, incidental, consequential, special, exemplary or punitive damages arising out of the use of the product, including, without limitation, property damage, loss of value of the product or any third party products that are used in or with the product, or loss of use of the product or any third party products that are used in or with the product.

