

INSTRUCTIONS

501CR – Ladder Mounted Chair Rack

PLEASE NOTE THE FOLLOWING SAFETY POINTS:

1. The ladder **MUST** be in good condition to use the chair rack.
2. Make sure to tighten the strap around the chairs as much as possible.
3. When the chairs are mounted they should **NOT** hang below the bumper. The chairs should be at or above the bumper to avoid the chairs being dragged.

INSTALLATION INSTRUCTIONS

Chair rack should be mounted as close as possible to the center stantion on the ladder.

Un-screw parts A & B from each other On both the top and bottom parts of the rack. Place part A on the back of the ladder and part B in the front of the ladder and screw them back together. Repeat the same for the bottom half of the rack.



PART B

PART A



Once one side is mounted and tightened properly repeat the same steps to the other half of the rack.



Remove pins to swing open the rack to allow easier access to the ladder. Replace the pin to hold open the rack. Once done remove the pins close the rack and reinsert the pins. **PLEASE NOTE THE PINS MUST ALWAYS BE IN PLACE REGARDLESS OF WHETHER THE RACK IS IN THE OPEN OR CLOSED POSITION.**

MOUNTING THE CHAIRS ONTO THE RACK

Undo the strap on the cradles. Load a maximum of 6 chairs onto the chair rack. Once centered on the rack tighten the straps around the chairs as tight as possible.

